

ASSEMBLY INSTRUCTION

SKU#252-768

Note: Please consult a qualified electrician if you are not certain of the installation.

CAUTION: Before starting the installation, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. Caulk to mounting surface at top and sides.

1. Fasten cross bar onto outlet box using 2 outlet box screws.
2. Screw the nipple into the bushing and fasten it by tightening the hex nut.
3. Using two pliers, twists open the links at the both ends of the chain. Hook one to the top loop and the other to bottom loop, and then close the links.
4. Weave the fixture wires and ground wire up through the bottom loop, though the chain links, through the top loop, and through the canopy.
5. Connect the wires white to white and black to black. Cover the connections using the wire connectors provided. Tie the ground wires from outlet box and from fixture to the ground screw on the cross bar.
6. Place the canopy over the mounting screws on the cross bar all the way to the ceiling and fasten it with the lock nuts provided until the canopy is held firmly against the ceiling.
7. Install the bulbs (included)
8. Place decorative pan, glass shade and decorative cover the nipple onto the fixture and fasten them with finial.

